

Handling

Do not drop the product, place a heavy object on it, submit it to a strong shock, or put pressure on it. The projector may fail.

Installation Location

- A TV, radio, or tuner may be affected by noise during use of the projector. If that happens, use the projector as far away as possible from such products.
- Do not place the projector near a credit card or other card. If placed near a card, the recorded data may be lost.
- The operating temperature range of the projector is 0°C to 35°C (32°F to 95°F). Using the projector in an extremely cold or hot location that is outside of the operating temperature range may cause a failure.
- Do not place the projector in a location where there is a lot of dust or cigarette smoke. Dust or cigarette tar getting on the internal parts (projection lens, etc.) of the unit may cause a failure.
- Do not place the projector in a location where the temperature becomes abnormally high or low when high humidity. The temperature will become especially high under the following conditions: when the projector is used in a room with closed windows in summer, leaving the product in such a location may cause abnormality and failure.

Connected Device

- The device to be connected also needs to be operated to project images. Also refer to the instruction manual of the device to be connected.
- Before connecting a mobile device to the projector, attach the battery pack to the mobile device. If a mobile device is connected without its battery attached, the data may be lost or the mobile device may fail.
- Reports have been received of cases where the data saved to the memory of a mobile device is suddenly lost regardless of whether or not it is used with the product. For details, refer to the instruction manual of the mobile device. Before starting to use a mobile device with this product, be sure to make a backup of the data saved to its memory. Nextorage assumes no responsibility whatsoever for the following matters arising from the use of this product:
 - Problems occurring while using the included items with other than this product
 - Problems with a computer, mobile phone, or other device caused to fail with this product
 - Problems of compatibility between this product and a specific device, software or peripheral device
 - Failure to operate with the installed software
 - Loss of data, damages, losses, financial damages, or claims from a third party
 - Other accidental or unavoidable damages
- If a problem has occurred, immediately stop use and contact the customer service department of the online store where you purchased the product.

Trademarks

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum, Inc. Other names and product names used in this instruction manual are generally trademarks or registered trademarks of their respective developer/manufacturer. However, the trademark and registered trademark symbols (™ and ®) are not included with all of the names and product names in this instruction manual.

HDMI

Projector unit

Dimensions: Approx. 83.0 mm × 17.2 mm × 95.0 mm (3 1/8 po × 7/8 po × 3 7/8 po) (W × D × H) (excluding largest protrusion)

Weight: Approx. 155 g (5.47 oz)

Operating temperature: 0°C to 35°C (32°F to 95°F)

Audio output: 1 (AUDIO OUT) terminal (Ø3.5 mm (1/8 in) stereo mini jack)

HDMI input: HDMI 1.4b (HDCP1.4)

Projection screen size: 30 to 120 inches

Brightness: 105 ANSI lumens

Color reproducibility: Full color (16,700,000 colors)

Aspect ratio: 16:9

Contrast ratio: 400:1

Light source life: Approx. 20,000 hours

Input: 9 VDC, 2.55 A

Output: 5 VDC, 1.5 A (1 port)

AC adapter

Input: 100 to 240 VAC, 50/60 Hz

Output (max.): 5 VDC, 3.0 A

9 VDC, 2.55 A (when USB PD compatible device is connected)

Dimensions: Approx. 44.0 mm × 26.0 mm × 57.0 mm (1 3/8 in × 1 1/8 in × 2 1/8 in) (W × D × H) (excluding power plug)

Weight: Approx. 65 g (2.29 oz)

Operating temperature: 0°C to 35°C (32°F to 95°F)

Please note that the specifications and appearance of the product are subject to change without notice for improvement.

LIMITED WARRANTY

United States and Canada only – 1 year

Nextorage Corporation ("Nextorage"), solely for purchases made in the United States and Canada, warrants this product against defects in material or workmanship for the original owner and any subsequent end user owner(s) ("you" or "your") for the time period set forth above as set forth herein.

Pursuant to this Limited Warranty, Nextorage will, at its option, (i) replace the product with a new or reconditioned/refurbished product of the same (or similar) model, (ii) refund the purchase price upon confirmation of "your" receipt or purchase record at the online store or retailer where "You" purchased the product. For purposes of this Limited Warranty, "reconditioned" or "refurbished" means a product or part that has been returned to its original specification. In the event of a defect, these are "your" exclusive remedies.

The product is not warranted that the operation of the product will be uninterrupted or error-free.

Term: For the time period set forth above from the original date of purchase of the product from the online store or retailer authorized by Nextorage to ship the product.

This Limited Warranty covers only the hardware components packaged with the product. It does not cover separate accessories, technical assistance for hardware or software usage and it does not cover any software products whether or not contained in the product, and other unless expressly provided for in a separate written agreement.

In order to receive warranty service, the product must be returned according to the procedures of the online store where it was purchased. To obtain warranty service, please contact the customer service department of the online store where you purchased the product.

Use of Your Personal Information. If you obtain service under this Limited Warranty, You authorize Nextorage to store, use and process information about the service provided to You and your contact information (including Your name, phone number, address, and e-mail address). Nextorage may use this information to perform service under this Limited Warranty in accordance with its Privacy Policy, which can be found here: <https://www.nextorage.net/en/privacy/>

Loss of Data: Nextorage cannot guarantee that it will be able to refund or exchange any product under this Limited Warranty without risk to loss of software or data. It is Your responsibility to remove or backup any removable media or parts, data, software or other materials You may have stored or preserved on Your product. It is likely that any media or parts, data, software, or other materials (like pictures, music, videos, etc.) will be lost or reformatted during service and Nextorage will not be responsible for any such damage or loss.

Refund/Replacement Warranty: This Limited Warranty shall apply to any replacement, reconditioned, or refurbished product for the Service under of the original Limited Warranty period or for ninety (90) days from the date of the replacement, whichever is longer. Any product replaced under this Limited Warranty will become the property of Nextorage. Any replacement reconditioned or refurbished product provided under this Limited Warranty may not match the original product, vary in color and/or cosmetic design from the original product and may not include any original engineering or similar customization/ personalization.

Exceptions: Nextorage is not responsible for, and this Limited Warranty does not cover, any damage arising from a failure to operate the product within its intended uses, or otherwise follow the owner's manual and safety instructions relating to the product's use and installation. Nextorage is not responsible for any labor costs You may incur relating to service from service providers other than from an online store's Customer Service where the product was purchased. This Limited Warranty only covers product issues caused by defects in material or workmanship during ordinary consumer use.

This Limited Warranty is not responsible for, and this Limited Warranty does not cover, any damage arising from a failure to operate the product within its intended uses, or otherwise follow the owner's manual and safety instructions relating to the product's use and installation. Nextorage is not responsible for any labor costs You may incur relating to service from service providers other than from an online store's Customer Service where the product was purchased. This Limited Warranty only covers product issues caused by defects in material or workmanship during ordinary consumer use.

Abnormality of unit

- Turn the power off and then back on.
- If the projector does not recover even after turning the power off and then back on, stop use and contact the customer service department of the online store where you purchased the product.

USB cable cannot be connected.

A USB-C cable with a different shaped connector is being used.

→ Connect a USB cable with the correct connector shape.

The USB cable is not connected correctly.

→ Connect the USB cable correctly.

A foreign object is stuck in the USB port.

→ Remove the foreign object stuck in the USB port.

Your device cannot be connected.

The device is not compatible with an HDMI connection.

- Check the specifications of your device, or contact the manufacturer or place of purchase of your device.

An abnormal sound is output from the built-in fan.

Abnormality of unit

- Stop use and contact the customer service department of the online store where you purchased the product.

malfunction, or failure to fail to the product resulting from servicing not authorized or performed by Nextorage. (x) computer or internet viruses, bugs, worms, or Trojan Horses; (xi) malfunctions due to peripherals/accessories; (xii) modifications of or to any part of the product, including "rooting" or other modifications to control the behavior of the product or any factory installed operating system; (xiii) use of the product with constant or repetitive recording applications such as drive recorders, surveillance cameras, server applications, and constant playback applications such as digital signage, or industrial applications; or (xiv) any product where the factory-serial number has been altered or removed from the product.

LIMITATION ON DAMAGES: Nextorage SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT. NOR SHALL RECOVERY OF ANY KIND AGAINST Nextorage BE GREATER THAN THE ORIGINAL PURCHASE PRICE OF THE PRODUCT FROM Nextorage OR AN AUTHORIZED ONLINE SHOP.

DURATION OF IMPLIED WARRANTIES OR CONDITIONS: EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to You. This Limited Warranty gives You specific legal rights and You may have other rights which vary from jurisdiction to jurisdiction.

For purchases made in the U.S.: Read the following Dispute Resolution/Arbitration provision carefully. It details Your rights and instructions should a dispute relate to the product arise.

What Happens If We Have A Dispute: Should a dispute or claim arise related to the product, Your purchase and/or use of the product, the terms of this Limited Warranty, or any service provided under the terms of this Limited Warranty (including any repair or replacement) ("Dispute"), You and Nextorage agree that the **Dispute shall be resolved exclusively through binding arbitration. You UNDERSTAND AND ACKNOWLEDGE THAT BY AGREEING TO ARBITRATION, YOU ARE GIVING UP THE RIGHT TO LITIGATE (OR PARTICIPATE IN AS A PARTY OR CLASS MEMBER) IN ANY DISPUTE.** **You also agree that ANY DISPUTE RESOLUTION PROCEEDING WILL ONLY CONCERN YOUR INDIVIDUAL CLAIMS, AND BOTH PARTIES AGREE NOT TO HAVE ANY DISPUTE HEARD AS A CLASS ACTION, REPRESENTATIVE ACTION, CONSOLIDATED ACTION, OR PRIVATE ATTORNEY GENERAL ACTION.** Despite the above, You have the right to litigate any Dispute on an individual basis in small claims court or other similar court of limited jurisdiction, to the extent the amount at issue does not exceed \$15,000, and as long as such court has proper jurisdiction and all other requirements (including the amount in controversy) are satisfied.

Arbitration Instructions. To begin Arbitration, either You or Nextorage must make a written demand to the other for arbitration. The Arbitration will take place before a single arbitrator. The arbitration will be administered in keeping with the Expedited Procedures of the American Arbitration Rules and the Supplementary Proceedings for Consumer-Related Disputes ("Rules") of the American Arbitration Association ("AAA"), when applicable and in effect when the claim is filed. You may get a copy of AAA's Rules by contacting AAA at (800) 778-7879 or visiting www.adr.org. The filing fees to begin and carry out arbitration will be shared between You and Nextorage, but in no event shall Your fees ever exceed the amount allowable by the special rules for Consumers Disputes provided for by AAA, at which point Nextorage will cover all additional administrative fees and expenses. This does not prohibit the Arbitrator from giving the winning party their fees and expenses of the arbitration when appropriate pursuant to the Rules. Unless You and Nextorage agree differently, the arbitration will take place in the country and state where You live, and applicable federal or state law shall govern the substance of any Dispute during the arbitration. However, the Federal Arbitration Act, 9 U.S.C. § 1, et seq., will govern the arbitration itself and any not state law on arbitration. The Arbitrator's decision will be binding and final, except for a limited right of appeal under the Federal Arbitration Act.

Opt-Out Instructions. IF YOU DO NOT WISH TO BE BOUND BY THE BINDING ARBITRATION PROVISION, THEN: (1) You must notify Nextorage in writing within 30 days of the date that You purchased the product, (2) Your written notification must be mailed to Nextorage Corporation, Kawasaki-eki-mae Tower River, 9F 12-1 Eki-Bancho, Kawasaki-ku, Kawasaki city Kanagawa 210-0007 Japan, And (3) Your written notification must include (a) Your NAME, (b) Your ADDRESS, (c) the DATE You purchased the product, and (d) a clear statement that "YOU DO NOT WISH TO RESOLVE DISPUTES WITH Nextorage THROUGH ARBITRATION AND/OR BE BOUND BY THE CLASS ACTION WAIVER". Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and You will continue to enjoy the benefits of the limited warranty.

Opt-Out Instructions. IF YOU DO NOT WISH TO BE BOUND BY THE BINDING ARBITRATION PROVISION, THEN: (1) You must notify Nextorage in writing within 30 days of the date that You purchased the product, (2) Your written notification must be mailed to Nextorage Corporation, Kawasaki-eki-mae Tower River, 9F 12-1 Eki-Bancho, Kawasaki-ku, Kawasaki city Kanagawa 210-0007 Japan, And (3) Your written notification must include (a) Your NAME, (b) Your ADDRESS, (c) the DATE You purchased the product, and (d) a clear statement that "YOU DO NOT WISH TO RESOLVE DISPUTES WITH Nextorage THROUGH ARBITRATION AND/OR BE BOUND BY THE CLASS ACTION WAIVER".

Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and You will continue to enjoy the benefits of the limited warranty.

For the Customers in the U.S.A.

NOT APPLICABLE IN CANADA, INCLUDING IN THE PROVINCE OF QUEBEC. (POUR LES CONSOMMATEURS AUX ETATS-UNIS. NON APPLICABLE AU CANADA, Y COMPRIS LA PROVINCE DE QUEBEC)

CAUTION:

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to obtain this equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The number below is for the FCC related matters only.

Supplier's Declaration of Conformity

Trade Name: Nextorage

Model: NMP-NX1, NMP-AD1

Responsible Party: Violette Engineering Corporation

Address: 313 Park Avenue Suite 300, Falls Church, VA 22046 USA

Mail: info@violetteengineering.com

For the Customers in Canada

CAN ICES-003 (B) / NMB-003 (B)

Français

Merci d'avoir acheté ce produit.

Ne vous fiez pas aux conseils de sécurité relatives aux produits électroniques peut entraîner un incendie ou des blessures.

Veillez lire attentivement ce manuel d'instructions pour garantir une utilisation sûre du produit. Après avoir lu ce manuel d'instructions, conservez-le dans un endroit sûr pour vous y référer au besoin.

Principales caractéristiques et fonctions

- Design compact qui s'intègre à votre intérieur
- Bras flexible pour faciliter la projection au plafond (également possible ailleurs qu'au plafond)
- Luminosité optimisée pour la projection nocturne
- Installation facile et maintien sécurisé grâce au clip de fixation

Précautions de sécurité

Les produits Nextorage sont conçus dans un grand souci de sécurité. Toutefois, une mauvaise utilisation des produits électroniques pourrait entraîner des blessures dues à un incendie ou à un choc électrique. Pour éviter tout accident, veillez à respecter les points suivants :

- Respectez les précautions de sécurité

Utilisez attentivement les précautions indiquées dans ce manuel d'instructions.

Ne pas utiliser en cas de dysfonctionnement

Si vous constatez une anomalie pendant l'utilisation ou des dommages, contactez immédiatement le service client du magasin en ligne où vous avez acheté le produit.

En cas d'anomalie

• En cas d'émission de fumée • Si vous sentez une odeur étrange • Si de l'eau ou un autre liquide pénètre dans le système • Si un corps étranger pénètre dans le système • Si ce produit tombe ou est endommagé

- ➔ Débranchez les câbles de votre appareil et de l'unité, puis coupez l'alimentation.
- ➔ Contactez le service client du magasin en ligne où vous avez acheté le produit.

• En cas d'émission de fumée • Si vous sentez une odeur étrange • Si de l'eau ou un autre liquide pénètre dans le système • Si un corps étranger pénètre dans le système • Si ce produit tombe ou est endommagé

• En cas d'émission de fumée • Si vous sentez une odeur étrange • Si de l'eau ou un autre liquide pénètre dans le système • Si un corps étranger pénètre dans le système • Si ce produit tombe ou est endommagé

Précautions générales concernant le produit

Si ce produit n'est pas utilisé correctement, il peut **générer de la chaleur, s'enflammer ou exploser, provoquer des brûlures, des blessures graves ou la perte de la vie**.

Pour éviter toute ingestion accidentelle et d'autres problèmes, veillez à respecter les points suivants :

- Ne provoquez pas de court-circuit. N'insérez pas d'épingle ou tout autre objet métallique dans l'unité et les ports.
- Utilisez le produit avec l'alimentation et la tension spécifiées. Une tension inappropriée pourrait provoquer un incendie, des brûlures ou un choc électrique.
- Ne démontez pas ou ne modifiez pas. Ne mettez pas le produit au feu et ne chauffez pas avec un appareil de chauffage tel qu'un four à micro-ondes ou tout autre four.
- Ne mouillez pas le produit avec des liquides tels que de l'eau, de l'eau de mer, du lait, des boissons gazeuses et de l'eau savonneuse, et ne le chargez ou ne le touchez pas lorsqu'il est mouillé. N'utilisez pas le produit s'il est mouillé.
- N'utilisez pas le produit à proximité d'un feu, en plein soleil, près d'un poêle, à l'intérieur d'une voiture exposée chaude ou dans tout autre endroit chaud.
- N'entrez de ventilation L'accumulation de chaleur dans l'unité peut provoquer un incendie ou une panne. N'obstruez et ne couvrez pas l'entrée de ventilation.
- LED USB OUT S'allume/clignote en vert ou en rouge pour indiquer l'état de l'unité.

En outre, n'utilisez pas le produit dans un environnement mal aéré, par exemple sous un manteau ou une couverture, ou dans un sac.

• Ne soumettez pas le produit à un choc ou à une force quelconque, par exemple en le frappant avec un marteau ou un autre objet, en posant des objets lourds dessus, en marchant dessus ou en le laissant tomber.

• Ne laissez pas les enfants utiliser le produit sans surveillance et gardez-le hors de portée des nourissons.

• Insérez complètement la fiche d'alimentation et le connecteur USB.

• Ne touchez pas le produit si vos mains sont mouillées.

• N'endommagez pas la fiche d'alimentation.

• Utilisez toujours le produit avec l'alimentation spécifiée (100 à 240 V CA).

• N'utilisez pas l'appareil d'une façon qui entraînerait un dépassement des valeurs nominales de la prise et des accessoires de câblage.

• N'utilisez pas le produit lorsque vous entrez dans un endroit où des gaz inflammables peuvent être générés, par exemple une station-service.

• Si vous constatez une anomalie telle qu'une odeur anormale, un bruit anormal, de la fumée, de la chaleur, une décoloration, une déformation ou un dommage pendant l'utilisation ou le stockage, procédez comme suit :

- ➔ Déconnectez le câble de l'appareil connecté.
- ➔ Mettez l'appareil connecté et l'unité hors tension.
- ➔ Cessez d'utiliser le produit.

• Ne regardez pas dans la lentille de projection. La lumière diffusée par ce projecteur peut avoir un effet néfaste si elle pénètre dans vos yeux.

• Ne regardez pas dans la lentille de projection, quelle que soit l'intensité de la source lumineuse.

• Lorsque vous regardez un écran, tenez-vous à une distance suffisante de celui-ci. Nous vous conseillons de vous tenir à une distance atteignant au moins 1,5 fois la longueur de la diagonale de l'écran.

• Ne placez pas d'objets lourds sur le câble USB. Un incendie, une brûlure ou un choc électrique peuvent se produire.

• Utilisez le produit dans un endroit où la température ambiante est comprise entre 0 °C et 35 °C (entre 32 °F et 95 °F).

• Ne touchez pas l'unité pendant une longue période au cours de son utilisation. Un contact prolongé avec la peau peut provoquer des brûlures superficielles.

Un contact indirect prolongé avec des vêtements peut également provoquer des brûlures superficielles.

Débranchez les câbles de l'unité et retirez la fiche d'alimentation de la prise après avoir utilisé le produit ou lorsque vous prévoyez de ne pas l'utiliser.

• N'installez pas le bras flexible dans un endroit instable.

• Si vous suspectez une anomalie ou un dysfonctionnement, débranchez la fiche d'alimentation de la prise.

• Vérifiez régulièrement que la poussière ne s'est pas accumulée sur les ports, les connecteurs et les aérations de l'unité, ainsi qu'entre la prise et la fiche d'alimentation.

• Vérifiez le sens de raccordement d'une borne de connexion avant de la raccorder.

• Ne touchez pas directement ou n'insérez pas votre doigt dans une pièce de connexion.

• N'utilisez pas ou ne stockez pas le produit dans un endroit très humide ou exposé à la fumée de cigarette.

• N'utilisez pas et ne stockez pas le produit dans un endroit poussiéreux ou ensoleillé.

De la poussière ou du sable pénétrant dans l'orifice d'aération au bas de l'unité pourrait provoquer une panne.

• N'insérez pas de corps étranger dans une aération.

• N'insérez pas vos ongles dans une aération, une borne ou une rainure de l'unité.

Vérification du contenu de l'emballage

S'il manque un article, contactez immédiatement le service client du magasin en ligne où vous avez acheté le produit.

- Projecteur NMP-NX1 (1)
- Projecteur NMP-AD1 (1)
- Bras flexible (1)
- Adaptateur secteur (1)
- Câble USB-C (compatible USB 2.0, 1.0 m (3,28 pi)) (1)
- Câble HDMI haute vitesse avec Ethernet (2,2 m (7,22 pi)) (1)
- Clips de câble (3)
- Jeu de documents imprimés (1)

Veillez noter que la garantie ne couvre pas les clips de câble.

Emplacement de projection

Réglez le bras flexible ou l'angle de l'unité de projection selon l'emplacement de projection (plafond ou mur).

Emplacement de montage

Choisissez l'emplacement de montage selon l'emplacement de projection. Le projecteur est conçu pour être utilisé fixe à l'endroit souhaité à l'aide du bras flexible. Lorsque vous utilisez le bras flexible, fixez-le à un endroit conforme aux conditions suivantes par souci de sécurité.

- Endroit avec une forme de panneau pouvant être saisi par le clip de fixation (épaisseur jusqu'à 55 mm (2 1/8 po)).
- Endroit où vous pouvez fixer solidement le système, sans qu'il oscille
- Endroit solide et capable de supporter le poids du projecteur et du bras flexible
- Endroit très stable avec une large masse

➔ Vérifiez que les surfaces du caoutchouc de fixation du clip de montage sont toutes en contact étroit avec les surfaces de montage.

➔ Lorsque vous réglez l'angle, procédez en tenant la poignée de fixation.

Distance de projection et taille de l'écran

La taille de l'écran de projection varie, comme l'illustre la figure A, selon la distance par rapport à la lentille de projection de l'unité.

Conseils

• La taille de l'écran est exécutée par une valeur correspondant à la longueur diagonale de l'écran en pouces. (Par exemple, la diagonale d'un écran de 120 pouces est 120 po, soit environ 305 cm.)

• Nous vous conseillons de régler les images projetées à une distance d'au moins 1,5 fois la longueur de la diagonale de l'écran.

• Si vous constatez une anomalie telle qu'une odeur anormale, un bruit anormal, de la fumée, de la chaleur, une décoloration, une déformation ou un dommage pendant l'utilisation ou le stockage, procédez comme suit :

➔ Déconnectez le câble de l'appareil connecté.

➔ Mettez l'appareil connecté et l'unité hors tension.

➔ Cessez d'utiliser le produit.

• Ne regardez pas dans la lentille de projection. La lumière diffusée par ce projecteur peut avoir un effet néfaste si elle pénètre dans vos yeux.

• Ne regardez pas dans la lentille de projection, quelle que soit l'intensité de la source lumineuse.

• Lorsque vous regardez un écran, tenez-vous à une distance suffisante de celui-ci. Nous vous conseillons de vous tenir à une distance atteignant au moins 1,5 fois la longueur de la diagonale de l'écran.

• Ne placez pas d'objets lourds sur le câble USB. Un incendie, une brûlure ou un choc électrique peuvent se produire.

• Utilisez le produit dans un endroit où la température ambiante est comprise entre 0 °C et 35 °C (entre 32 °F et 95 °F).

• Ne touchez pas l'unité pendant une longue période au cours de son utilisation. Un contact prolongé avec la peau peut provoquer des brûlures superficielles.

Un contact indirect prolongé avec des vêtements peut également provoquer des brûlures superficielles.

Débranchez les câbles de l'unité et retirez la fiche d'alimentation de la prise après avoir utilisé le produit ou lorsque vous prévoyez de ne pas l'utiliser.

• N'installez pas le bras flexible dans un endroit instable.

• Si vous suspectez une anomalie ou un dysfonctionnement, débranchez la fiche d'alimentation de la prise.

• Vérifiez régulièrement que la poussière ne s'est pas accumulée sur les ports, les connecteurs et les aérations de l'unité, ainsi qu'entre la prise et la fiche d'alimentation.

• Vérifiez le sens de raccordement d'une borne de connexion avant de la raccorder.

• Ne touchez pas directement ou n'insérez pas votre doigt dans une pièce de connexion.

• N'utilisez pas ou ne stockez pas le produit dans un endroit très humide ou exposé à la fum